

GSP 8

[Back to Table of Contents](#)

A. General Description

Use this procedure to sample hot poured joint sealer.

1. Pre-tested Hot Poured Joint Sealer
 - a. Ensure that the hot poured joint sealer is pre-tested, as evidenced by the “GDT” inspection stamp on the shipment. You do not need to sample or test it.
 - b. Use form 168 (miscellaneous test report) to report the vendor, manufacturer, trade name, lot number, quantity represented, and GDT inspection number.
 - c. Submit the form to the [Office of Materials and Research](#).
2. Untested Hot Poured Joint Sealer
 - a. Cut a sample from the material.
 - b. Properly wrap the sample to prevent contamination by foreign material.
 - c. Identify the samples on Form 170.
 - d. Submit the sample directly to the [Office of Materials and Research](#) at least two weeks before use.
 - e. Report test results of hot poured joint sealers on Form 168.