

**PROCEDURE FOR THE CALIBRATION OF THE MARSHALL  
AUTOMATIC HAMMER TO THE HAND HAMMER  
AASHTO T 245**

**A. PURPOSE**

This method is intended to provide instruction for the calibration of mechanically operated hammers to yield results comparable to that of the hand operated hammer as specified in AASHTO T 245, Section 2.3. The average actual density obtained using a mechanical hammer is compared to the average actual density obtained using a hand hammer. The number of blows with the mechanical hammer is adjusted accordingly. The hammers are calibrated from 50 to 75 blows per face.

**B. PROCEDURE      Calibrating the mechanical hammer.**

1. Prepare 28 specimens of “E” mix with an identical mixture and compact them in accordance with the following schedule per AASHTO T 245.

**COMPACTION SCHEDULE**

No. of Specimens	No. of blows per face	Type Hammer	% AC
5	50	Hand	50 BL OPT
5	75	Hand	75 BL OPT
3	50	Mechanical	50 BL OPT
3	60	Mechanical	50 BL OPT
3	70	Mechanical	50 BL OPT
3	70	Mechanical	75 BL OPT
3	80	Mechanical	75 BL OPT
3	90	Mechanical	75 BL OPT

2. Calculate the average actual density for each set of specimens for both the hand-held and the mechanical hammers in accordance with GDT-39, “Method of Test for Specific Gravity of Compressed Bituminous Mixtures.”
3. Plot the density versus the number of blows for the mechanized hammers. Draw a “best-fit” curve through the mechanical hammer data points, creating a separate curve for both the 50 blow and 75 blow data. Draw a straight line across the graph at the point representing the average hand-held hammer density.

**C. ADJUSTMENTS FOR THE MECHANICAL HAMMER**

The point at which the hand hammer average and the “best-fit” curve for each of the mechanical hammer results intersect will identify the number of blows required using the mechanical hammer to yield either 50 or 75 blow hand hammer results.

**D. TOLERANCE**

The number of blows is adjusted so as to produce the same compaction produced by the hand hammer.

# EQUIPMENT CALIBRATION RECORD

Calibrated By: _____	Date: _____
Equipment: <u>Automatic Mechanical Marshall Hammer</u>	Location (Lab): _____
Identification No.: _____	Calibration Frequency: <u>12 months</u>
Previous Calibration Date: _____	Next Due Date: _____
Verification Equipment Used:    Calibrated scales, SN: _____                      Hand Hammer	
Calibration Procedure: <u>(In-house) OMR-CVP-26 / AASHTO T 245</u>	

## Hand Hammer

*Five (5) specimens compacted by hand at 50 blows*

<u>Specimen Number</u>	<u>Weight</u>
1	_____
2	_____
3	_____
4	_____
5	_____
Average Density	_____

*Five (5) specimens compacted by hand at 75 blows*

<u>Specimen Number</u>	<u>Weight</u>
1	_____
2	_____
3	_____
4	_____
5	_____
Average Density	_____

## Mechanical Hammer

*50 Blows*

1	_____
2	_____
3	_____
Avg. Density	_____

*80 Blows*

1	_____
2	_____
3	_____
Avg. Density	_____

*60 Blows*

1	_____
2	_____
3	_____
Avg. Density	_____

*90 Blows*

1	_____
2	_____
3	_____
Avg. Density	_____

*70 Blows*

1	_____
2	_____
3	_____
Avg. Density	_____

Use graph paper to plot density versus number of blows.  
Follow instructions to determine correct number of blows.

Number of blow required to calibrate to a hand hammer \_\_\_\_\_