



NOTES:

1. BEGINNING 600 mm BELOW THE TOE OF THE SLOPE, A 3.0 m ± WIDE BENCH AND DRAINAGE TRENCH IS CUT INTO SLOPE AS SHOWN. # 89 STONES AND PERFORATED UNDERDRAIN PIPE ARE THEN PLACED INTO THE TRENCH.
2. THE PREFABRICATED DRAIN SHALL BE TIED INTO THE DRAINAGE TRENCH AS SHOWN, SOLID UNDERDRAIN OR SLOPE DRAINS ARE TIED INTO THE PERFORATED PIPES WITH "T" CONNECTORS AT INTERVALS OF 60 m ± .
3. TYPE "B" GEOGRID TO BE PLACED AT 300 mm INTERVALS (VERTICALLY) BEGINNING 600 mm ABOVE THE BOTTOM OF THE BENCH.
4. THE PREFABRICATED DRAIN SHALL BE AS PER GA. QUALIFIED PRODUCTS LIST NO. 47

DETAIL APPLIES	LOCATION
STATION TO STATION	
3+000 ± TO 3+020 ±	L.T.

DRAINAGE DETAIL FOR RECONSTRUCTED CUT SECTION

NO SCALE